

Aim → To determine the specific resistance of the material of given wire using Carey Foster's bridge wire.

### Apparatus

- (1) Carey Foster's bridge
- (2) Decimal ohm box
- (3) Leclanche cell
- (4) Galvanometer
- (5) Thick copper strip
- (6) Plug key
- (7) Given wire
- (8) Screw gauge
- (9) Rehosfat (10-20 Ω)
- (10) Sand papers and connection wires.

### Formula Used

The resistance per unit length of the bridge wire is given by the formula.

$$R - R' = \rho(l_2 - l_1) \quad \rho = \frac{R}{l_2 - l_1} \quad [\text{when } R' \neq 0]$$

where  $l_1$  &  $l_2$  are the length of the balance

point on the bridge wire before & after interchanging the resistance.

The specific resistance can be calculated as :


$$k_1 = \frac{R' \pi r^2}{l} \text{ n cm.}$$

where  $r$  is the radius &  $l$  is the length of given wire.

Specific resistance is the resistance offered by a conductor whose length is 1 cm & area of cross-section is  $1 \text{ cm}^2$ , the current flowing normally to the face.

Observation :-

S.No.	Resistance introduced from R.B 'R' (ohm)	Position of balance ( $l_2 - l_1$ ) point (cm)	$\frac{R}{l_2 - l_1}$	Mean dimension.
		$l_1$	$l_2$	
1.	0.1	14.5	17.3	0.035 $P = 0.141$
2	0.2	1.8	2.5	0.285
3	0.3	41.8	44.3	0.12 0.14
4	0.4	4.1	45.1	0.1 0.09
5	0.5	2.4	5.3	0.09 0.172



Expt. No. \_\_\_\_\_

Page No. 3 Date \_\_\_\_\_

### Determination of Resistance of wire

No.	Resistance introduced from RB 'R' (ohm)	Position of balance point (l <sub>2</sub> - l' <sub>1</sub> ) (cm)	Resistance of wire R' = R(l <sub>2</sub> - l' <sub>1</sub> )
1.	0.1	42.9	42.9 1 0.042
2.	0.2	43.4	43.4 0.3 0.0157
3.	0.3	42.8	42.8 0.4 0.0243
4.	0.4	42.1	42.1 1.7 0.159
5.	0.5	42.2	42.2 2.7 0.117

$$\text{Mean} = \frac{0.718}{5} = 0.144 \Omega$$

Length of the wire outside the terminal = l = 7 cm

### Result

The specific resistance of a given wire =  $47 \times 10^{-6}$  ohm cm  
 $k = \frac{R}{l^2} = \frac{0.144}{(3.17)^2} = 4.7 \times 10^{-6}$  ohm cm

$$k = \frac{R}{l^2} = \frac{0.144}{(3.17)^2} = 4.7 \times 10^{-6} \text{ ohm cm}$$

Standard value  $\Rightarrow 4.9 \times 10^{-6} \text{ ohm cm}$

$$\% \text{ error} = \frac{\text{difference}}{\text{actual value}} \times 100\% = 4.08\%$$

Teacher's Signature \_\_\_\_\_

## VIVA - VOCE

- 1) What is specific resistance? What is its unit?  
 → Specific resistance of a substance is defined as the resistance of a piece of the unit length & unit area of cross section.

$$k = R \frac{A}{l}$$

If  $A = 1 \text{ cm}^2$   $l = 1 \text{ cm}$   $k_s = R \text{ ohm-cm}$ .

- 2) Has specific resistance the same value for all materials?  
 → No, it is different for different materials.
- 3) Does temperature any effect on the specific resistance?  
 → Yes, the specific resistance of pure metals decreases with temperature.
- 4) If a wire of certain length is stretched to twice to its original length, how will its specific change?  
 → Specific resistance will remain the same as it depends on the material of the wire.

5) What is the effect of using the effective length of a Caeney Foster's bridge wire?

→ By doing this, accuracy of the result will be increased.

6) Why the copper strip fitted on the Caeney Foster's bridge is made thick?

→ So that it may offer a negligible resistance.

7) What is the material of the Caeney Foster's bridge wire?

→ The bridge wire is of constantan & manganin.

8) Why should the jockey be not pressed too hard?

→ If jockey is pressed too hard, the wire will become flat at that point & its area of cross-section will no longer be uniform & hence the resistance of the wire will not be proportional to its length.

9) What is the maximum & min. diff. in resistance that you can measure with Caeney Foster's bridge wire?

→ Min. diff. measured by this bridge wire is resistance of one millimeter length of bridge wire.

Max. diff. is equal to resistance of total length of bridge wire.

**Aim :-** To determine the electro-chemical equivalent (ECE) of copper using a tangent Galvanometer.

**Apparatus Required :-**

- 1) Copper Voltmeter
- 2) Tangent galvanometer
- 3) Rheostat
- 4) One way key
- 5) Battery
- 6) Commutator
- 7) Stop Watch
- 8) Ammeter
- 9) Sand paper & Connecting wires

**Theory :-**

- (i) Copper Voltmeter  $\rightarrow$  It consists of a glass vessel containing 16 to 22% sol. of  $CuSO_4$  with a few drops of sulphuric acid ( $H_2SO_4$ ). The anode consists of a focus of copper plates.

- (ii) Faraday's law of electrolysis.
- (iii) Acc. to first law mass ( $m$ ) deposited

$$m = ZIT$$

where,  $Z$  is constant is called the electro-chemical equivalent of the substance.

For tangent galvanometer,  $I = \frac{10 \pi H \tan \theta}{2 \pi m}$

$$Z = \frac{2 \pi m}{10 \pi H \tan \theta}$$

Teacher's Signature




Table four determination of  $\theta$

Time Minutes	Def. of pointer from direct current		Def. of pointer from alternating current		Mean	$\tan \theta$
	Left point $\theta_1$	Right point $\theta_2$	Left point $\theta_3$	Right point $\theta_4$		
0	45	45	45	45		
5	45	45	44	44		
10	40	40	44	44	$40 + 45^\circ$	$\tan \theta$ $\tan 45^\circ = 1$
15	40	40	43	43		
20	49	49	42	42		

Calculation :-

$$\begin{aligned}
 Z &= \frac{\theta \pi n \times m}{1000 H \tan \theta \times t} \\
 &= \frac{\theta \times 3.14 \times 50 \times 0.2}{10 \times 7.5 \times 0.339 \times 1 \times 2400} \\
 &= \frac{62.8}{61000} \\
 &= 0.00129 \text{ gm/c}
 \end{aligned}$$

Expt. No. \_\_\_\_\_

Page No. 7 Date \_\_\_\_\_

In case of Helmholtz galvanometer  $I = \frac{50\pi^2 \times H}{32\pi n} - tan \theta$

Observations:-

Value of field ( $H$ ) = 0.339 oersteds

Radius of coil ( $n$ ) = 7.5 cm

No. of turns in each coil ( $n$ ) = 50

Mass of copper plate before deposition of copper = 29.7 gm

Mass of copper plate after deposition of copper = 30.1 gm

Mass of copper deposited  $m = 30.1 - 29.7$   
 $= 0.2 \text{ gm.}$

Initial reading of stop watch = 0 sec.

Final reading of stop watch

Total time taken =  $40 \times 60 = 2400 \text{ sec.}$

Result :- The E.C.E of copper =  $0.0129 \text{ gm/c}$   
 Standard value of E.C.E (Cu) =  $0.00032 \text{ gm/c}$

Precautions:-

1) The magnetometer box should be carefully leveled so that the magnetic needle moves freely in a horizontal plane.

2) The coil should be set in magnetic meridian

3) All the magnetic materials of current carrying conductor should be set at a considerable distance from the apparatus.

Teacher's Signature \_\_\_\_\_

## VIVA - VOCE

- 1) What is meant by electrochemical equivalent (E.C.E) of element ?  
 → From first law of electrolysis  $m \propto I t$   
 $m = Z \propto I t$  is constant of proportionality & is called electrochemical equivalent (E.C.E)
- 2) What would you define E.C.E of an element or a substance.  
 → E.C.E of an element or a substance will be defined as the mass of it which is liberated when one coulomb of electricity flows through the electrolyte.
- 3) What is the unit of E.C.E ?  
 → The unit of E.C.E is  $\text{kg}/\text{Coulomb}$ .
- 4) What is electrolysis ?  
 → It is a process of decomposing an electrolyte by the passage of current.
- 5) What are electrodes ?  
 → The metallic conductors through which the current leaves or enters the electrolyte are called electrodes.

Table for Calibration of Voltmeter:-

Sl. No.	Voltmeter readings $V_1$	Balancing length of the potentiometer wire $L_2$	$V_2 = E \times \frac{L_2}{L_1}$	Error $V_2 - V_1$
No.	No. of complete wires	length of string wire	Total $L_2$	
1.	0.1	0	72.5	$72.5 \times \frac{1000}{1000} = 0.0196$
2.	0.2	1	140	$140 \times \frac{1000}{1000} = 0.031$
3.	0.3	1	164	$164 \times \frac{1000}{1000} = 0.0294$
4.	0.4	2	247	$247 \times \frac{1000}{1000} = 0.0076$
5.	0.5	2	361	$361 \times \frac{1000}{1000} = 0.0694$

Expt. No. 5

Page No. 10 Date 19/09/2019

Aim:- To calibrate a Voltmeter with a potentiometer.

Apparatus Required:-

- 1) Potentiometer
- 2) Storage battery (two)
- 3) Rheostats (series of 120 ohm)
- 4) Standard cell.
- 5) Galvanometer
- 6) Voltmeter
- 7) One way key (two)
- 8) Two way key.
- 9) Connection wires & sand paper.

Formula Used :-

The error in voltmeter reading is given by  $V_2 - V_1 = (E L_2 / L_1) - V_1$  where,

$V_1$  = potential diff. b/w two points (voltmeter reading)

$V_2$  = potential diff. b/w the same two points (potentiometer reading)

$E$  = E.M.F of the standard cell.


$L_1$  = length of the potentiometer wire corresponding to E.M.F of standard cell.

$L_2$  = length of potentiometer wire corresponding to potential difference  $V_2$ .

Teacher's Signature \_\_\_\_\_

Calculations :-

$$\text{Potential gradient } k = \frac{E}{L_1} = 1.65 \times 10^{-2} \text{ volt/cm.}$$



Expt. No. \_\_\_\_\_

Page No. 11 Date \_\_\_\_\_

Theory :- The checking up the accuracy of voltmeter readings is known as calibration of voltmeter. This calibration is done by using potentiometer because it does not draw any current at null point.

Observation :- 1) length of the potentiometer wire corresponding to E.M.F of standard cell,  
 $L_1 \text{ cm} = 1000 \text{ cm.}$


- 2) E.M.F of standard cell  $E = 1.65 \text{ Volt}$   
3) Potential gradient  $= E/L_1 \Rightarrow 0.001$

Result :- The graph of emf  $(V_2 - V_1)$  versus voltmeter reading of  $V_1$  is zig-zag in shape if this curve is called as calibration curve. This curve is point-to-point curve.

Precautions :-

- 1) The E.M.F of the battery should be greater than the E.M.F of the standard cell.
- 2) The (the) terminals should be connected at the point 't'.
- 3) Jockey should not be moved on the potentiometer wire.
- 4) Voltmeter should be connected in parallel.

Teacher's Signature \_\_\_\_\_



Expt. No. \_\_\_\_\_

Page No. 12 Date \_\_\_\_\_

## VIVA - VOCE

1. What is a Potentiometer?

→ A potentiometer consists of a long uniform wire of constantan or manganin fixed on a wooden board in which a steady current is allowed to flow by connecting it to a source of constant E.N.F.

2. Why is it called a Potentiometer?

→ It is called as potentiometer because it measures potential difference b/w any two points.

3. What is the principle of a Potentiometer?

→ It works on the fact that constant current fell of potential along a uniform wire is proportional to its length.


4. Why do we use constantan or manganin wire?

→ Both of these wires possess high specific resistance & low temperature coefficient.

5. What do you mean by calibration of a voltmeter?

→ Calibration of voltmeter means checking up the accuracy of its readings.

Teacher's Signature \_\_\_\_\_



Experimental arrangement for Newton's ring.

Expt. No. 4.

Page No. 14 Date 19/9/2019

Objective :- Study of Interference of light.

Aim:- To determine the wavelength of monochromatic (sodium) light by Newton's rings.

Apparatus :-

- 1) Travelling microscope
- 2)  $45^\circ$  inclined glass plate
- 3) Optically plane glass plate
- 4) Plane convex lens.
- 5) Reading lens & lamp
- 6) 4 Spherometer.

Formula Used :-

The wavelength  $\lambda$  of monochromatic light  
is given by 
$$\lambda = \frac{D_{np} - D_n}{4PR}$$

Lithens.


$D_{np}$  = diameter of the  $(n+p)$ th bright ring.

$D_n$  = diameter of  $n$ th bright ring

$R$  = radius of curvature of convex surface  
of the plano convex lens & is given by

$$R = \frac{a^2 + h}{2a} \quad \text{where 'a' is the dis. b/w two legs & } h \text{ height of convexity of lens.}$$

Teacher's Signature \_\_\_\_\_



Theory:- When a plano-convex lens with its convex surface is placed on a plane glass-plate, an air film of gradually varying thickness is formed b/w the two. If monochromatic light is allowed to fall normally & viewed as shown in fig., then alternate dark fringes & bright circular fringes are observed. These rings are known as Newton's rings.

Newton's rings are formed because of the interference b/w the waves reflected from top & bottom surfaces of air film formed b/w the plates.

We have for the diameter of the  $n^{\text{th}}$  dark fringe.

$$D_n = 4n\lambda R$$

Similarly diameter for  $(n+p)^{\text{th}}$  dark fringe

$$D_{n+p} = 4(n+p)\lambda R$$

$$D_{n+p}^2 - D_n^2 = 4pR\lambda$$

$$\frac{D_{n+p}^2 - D_n^2}{4pR} = \lambda$$

So,  $\lambda$  can be calculated using this formula.

Observations :- Least count of the vernier of travelling microscope =  $0.01 \text{ mm}$ .

## Calculations

$$R = 100 \text{ cm} \quad f = 6$$

$$\frac{f}{4R} = \frac{D_{hp} - D_h}{D_h}$$

$$= \frac{15.24 \times 10^{-2}}{4 \times 6 \times 100}$$

$$= 6.35 \times 10^{-5}$$

$$= 6350 \times 10^{-8} \text{ cm}$$

$$= 6350 \text{ Å}$$

Expt. No. \_\_\_\_\_

Page No. 16 Date \_\_\_\_\_

Table :- Diameter of the rings.

n	micrometer Left hand side		Right hand side		D <sub>h</sub> (mm)	D <sub>h</sub> <sup>2</sup> mm <sup>2</sup>	D <sub>hp</sub> -D <sub>h</sub> <sup>2</sup> mm <sup>2</sup>	Mean P.G	
	N.S (mm)	VS (mm)	N.S (mm)	VS (mm)					
20	33	0.25	33.25	26	0.96	26.96	6.29	39.56	1.2
18	33	0.72	33.72	26.5	0.11	26.65	7.11	50.55	32.06
16	33	0.82	33.82	26.5	0.24	26.74	6.78	45.96	17.34
14	32.5	0.38	32.08	27	0.63	27.63	5.25	27.56	3.45
12	32	0.12	32.12	27	0.82	27.82	4.30	18.49	7.34
10	32	0.90	32.90	27.5	0.05	27.55	5.35	28.62	22.02
8	32	0.67	32.67	27.5	0.25	27.75	4.80	23.81	12.19
6	31.5	0.39	31.89	28	0.55	28.55	3.34	11.51	27.83
4	31	0.47	31.47	28	0.90	28.90	2.57	6.60	31.77
2	31	0.69	31.69	28	0.28	28.28	3.41	11.62	27.79

Radius of curvature of convex surface R(Given) = 100 cm.

Result :-

The wavelength of sodium light was determined  
is

Teacher's Signature \_\_\_\_\_

# VIVA - VOCE

---



---

1. What are Newton's rings?

→ When a plano-convex lens of large radius of curvature is placed with its convex surface in contact with a plane glass plate, an air film is formed b/w the lower surface of the lens & upper surface of the plate. If monochromatic light is allowed to fall normally, on this film, a system of alternate bright & dark concentric rings with their centre dark is formed. These are called Newton's rings.

2. Why these rings are circular?

→ These rings are foci of constant thickness of the air film film & these foci are concentric circles hence fringe are circular.

3. Why do the rings get closer as the order of rings increases?

→ Because radius of dark ring  $D_n \propto \sqrt{n}$  while for bright ring  $D_n \propto \sqrt{2n+1}$  i.e., sq. root of odd natural no.

4. Why is the centre of the ring dark?

- Because effective path difference  $P = 2t + \lambda/2$ . At the point of contact  $t=0 \therefore P=\lambda/2$ . This is the cond. for minimum intensity. Hence the centre of the ring is dark.
- 5- But sometimes it is observed that centre is bright why?
- This is because dust particle comes b/w the two surfaces at the point of contact.
- 6- If sodium lamp is replaced by white light source then what will happen?
- Few coloured fringes will be observed near the centre.
- 7- If a few drops of transparent liquid are introduced b/w the lens & plate, then what will happen?
- The diameter of fringes is contracted.
- 8- On what factors, does the diameter of ring depend.
- (1) Radius of curvature  $R$  of convex lens.  
 (2) Refractive Index  
 (3) Wavelength of light used.

~~Ok~~  
1/1

Objective :- To determine the wavelength of spectral lines of mercury light by a plane transmission grating.

Apparatus :- Mercury lamp, spectrometer, a spirit level, grating with stand, table lamp & a reading lens.

Formula Used :- The wavelength of any spectral line can be obtained from the formula.

$$(e+d) \sin \theta = n\lambda$$

$$\lambda = \frac{(e+d) \sin \theta}{n}$$

where,

$(e+d)$  = grating element

$\theta$  = angle of diffraction

$N$  = order of spectrum.

Observation :-

Least count of spectrometer = 30 sec.

No. of lines per inch on the grating  $N = 15500$

Grating element ( $e+d$ ) =  $2.54/\text{in}$ .

### Observation table

Order of Spectrum of light	Colour	kind of Venier on left	Spectrum		$\theta = (a-b)$	Mean $\theta$ in degree.				
			NS	VS	Total					
First	Violet	V <sub>1</sub>	143	0	143	174.5	10	174.6	15.75	15.915°
		V <sub>2</sub>	323	24	323.44	355.0	30	355.6	16.08	
Green	Green	V <sub>1</sub>	139.5	20	139.90	178	20	178.4	19.25	19.575°
		V <sub>2</sub>	319	20	319.90	388.5	60	388.7	19.9	

### Calculation

$$\text{Grating element } (e+d) = 2.54 \text{ N}$$

N = 15000 (Given)

$$\frac{(e+d)}{n} = \frac{2.54}{15000} \text{ cm} \Rightarrow \frac{2.54}{15000 \times 10^2} \text{ m}$$

$$\lambda = \frac{(e+d) \sin \theta}{n}$$

where n=1

$$\lambda = (e+d) \sin \theta$$

$$\lambda_V = \frac{2.54}{15000 \times 10^2} \times \sin (15.915) \quad \lambda_V = \frac{2.54}{15000 \times 10^2} \times \sin (19.575)$$

$$= 4.643 \times 10^{-7} \quad = 5.6733 \times 10^{-7}$$

$$= 4643.3 \text{ A}^\circ \quad = 5.6732 \text{ A}^\circ$$

Expt. No. \_\_\_\_\_

Page No. 20 Date \_\_\_\_\_

Result :-

$$\text{Violet light} = 4643.3 \text{ A}^\circ$$

$$\text{Green light} = 5673.35 \text{ A}^\circ$$

VIVA - VOCE

1) Define Grating

→ It is an arrangement in which there is a fine quality of glass in which parallel lines are ruled equidistant with diamond point by an automatic shifting machine. The ruled lines works as opaque & spacing works as transparent.


2) What is active medium?

→ It may be solid, liq. or gas which achieves population inversion.

3) What is the action of the optical resonator?

→ It is the combination of two reflecting mirror which is used to increase the intensity of laser light.

Teacher's Signature \_\_\_\_\_



Expt. No. 6

Page No. 21 Date \_\_\_\_\_

Objective :- To determine the specific rotation of cane-sugar sol. using half shade polarimeter.

Apparatus Required :-  
 1) half - Shade polarimeter  
 2) Sodium lamp  
 3) 50 c.c flask  
 4) Two beakers  
 5) Analytical balance  
 6) weight box.

Formula Used :-  $S = \frac{\theta}{l \times c}$  degree (dm)<sup>-1</sup> (gm/cm<sup>3</sup>)<sup>-1</sup>

where,

$\theta$  = rotation in degrees

$l$  = length of the sol. in decimeters

$c$  = conc. of sol. in gm/cm<sup>3</sup>.

Theory :- The specific rotation 'S' of a substance at a given temp. & for a given wavelength of light is defined as the rotation (in degree) produced by one decimeter length of the substance in sol. when its conc. is 1 gm/cm<sup>3</sup>. Laurent's half - shade polarimeter.

It is an instrument used for measuring the

Teacher's Signature \_\_\_\_\_

Table 1. Distilled water in the tube

S.No.	First position of the analyser			Position of analyser (S) apart from the first setting			$\theta = \frac{c + f}{4}$									
	Clockwise rotation (e)	Anticlockwise rotation (f)	rotation (g)	Clockwise rotation (h)	Anticlockwise rotation (i)	Total										
M.S	V.S	Total	M.S	V.S	Total	M.S	V.S	Total								
1.	70.3	3	73.3	33.4	6	33.6	4	80.8	6	86.8	10.2	3	87.2	2	92.2	4.3
2.	90.1	6	96.1	310.6	6	316.6	90.4	6	96.4	300.6	6	306.6	206.6	204		
3.	90.9	6	96.9	310.8	6	306.8	110.1	6	116.1	290.8	6	296.8	204.4	15		

Table 2 Cane Sugar sol. in the tube

Conc.	First position of the analyser			After $180^\circ$			$\theta = \frac{c + f}{4}$								
	Clock wise rotation (e)	Anticlockwise rotation (f)	rotation (g)	Clockwise rotation (h)	Anticlockwise rotation (i)	Total									
M.S	V.S	Total	M.S	V.S	Total	M.S	V.S	Total							
1.	44	3	77	329	3	342	270	3	273	146	3	149	210.25		
2.	88	3	91	330	3	333	289	3	292	132	3	135	218.75		
3.	103	3	106	323	3	326	313	3	316	126	3	123	217.75		

Expt. No. \_\_\_\_\_

Page No. 22 Date \_\_\_\_\_

optical rotation of certain substances.

Monochromatic light from source 'S' usually a sodium lamp after passing through a slit is rendered  $\parallel$  by a concave lens L & falls on a polarising Nicol N<sub>1</sub>. After passing through Nicol N<sub>1</sub>, the light becomes plane-polarised. This light passes through a half-shade device Laurent's plate H & then through a tube containing the optically active sol. (Cane sugar sol. in this case) & then falls on the analysing Nicol N<sub>2</sub>. The emergent light is viewed through a telescope T. The analysing Nicol N<sub>2</sub> can be rotated about the light axis, & its rotation can be measured on a circular degree scale by means of a vernier.

Observations :- Least count of vernier of the analyser = 0.1'

Mass of sugar = 2 gm

length of the tube = 20 cm one decimeter

Result :- The specific rotation of cane sugar sol. for sodium light is  $+68.5^\circ$   $(dm)^{-1}$   $(gm/cc)^{-1}$   
Standard value =  $+66.5^\circ$   $(dm)^{-1}$   $(gm/cc)^{-1}$

Teacher's Signature \_\_\_\_\_

### Calculations

Mean Value of  $\theta_1 = 203.72$

Mean value of  $\theta_2 = 218.58$

$$\text{Angle of rotation} = \theta = \theta_1 - \theta_2 = 10.06$$

$$S_1 = \frac{\theta}{d \times C_1}, \quad S_2 = \frac{\theta}{d \times C_2}, \quad S_3 = \frac{\theta}{d \times C_3}$$

$$\text{Average value of } S = \frac{S_1 + S_2 + S_3}{3} = + 68.5^\circ \text{ degree per cm per unit conc}$$

Expt. No. \_\_\_\_\_

Page No. 23 Date \_\_\_\_\_

### Precautions :-

- 1) There should be no air bubble in the soln contained in the polarimeter tube.
- 2) The cap of the tube should not be tightly screwed as to strain the glass which allows plane polarized light to pass through the soln.

### VIVA - VOCE

- 1) What is a polarimeter?  
→ It is an instrument used for measuring the angle of rotation of the plane of polarization by an optically active substance (Cane sugar soln in this case).
- 2) What is mean by polarized light?  
→ The light which has acquired the property of one-sidedness is called polarized light.
- 3) What do you understand by plane polarized light?  
→ When vibration takes place only in one direction to the plane through the axis of a beam, light is said to be plane polarized.

Teacher's Signature \_\_\_\_\_

4) Which crystal you are using in the experiment?  
→ Nicol prism.

5) Name three method by which you can produce plane polarized light.  
→ 1) Reflection 2) Refraction 3) Double refraction.

6) How many types of optically active substances are there?  
→ There are two types of substances.  
(1) Dextro-rotatory are right-handed  
(2) Laevo-rotatory are left-handed.

7) Where is the half-shade plate fitted in the polarimeter?  
→ This is fitted b/w the polarizer & the polarimeter tube containing the optically active sol.

8) Which source of light is used for Laurent's half-shade polarimeter?  
→ Sodium lamp.

9) Which source of light is used for Bi quartz polarimeter?


→ White light.

10) What is the standard value of specific rotation of cane sugar sol.?

→ Specific rotation of cane sugar sol. is  $+66.5^{\circ}(\text{clm})^{-1}$   
 $(\text{gm/cc})^{-1}$ .

Dr





(a)

Expt. No. 7

Page No. 26 . Date 07/11/2019.

AIM

Objectives :- To determine focal length of comb. of two lenses separated by distance & verify the formula for focal length of comb. of lens.

$$\frac{1}{F} = \frac{1}{f_1} + \frac{1}{f_2} - \frac{n}{f_1 f_2}$$

where

$F$  = focal length of combination

$f_1$  = focal length of the first lens.  
 $f_2$  = " " " " second "

and.

$n$  = Dis. b/w the two lenses.

Apparatus Required :-

Nodal-slide assembly (consisting of an optical bench, plane mirror, cross-slit and lamp) & the two given lenses.

Principle :- The focal length of a lens system is the distance b/w its principal point & the corresponding focal points. The principal points coincide with the corresponding nodal points when the media are the same on both the sides of the system (here air). Thus the focal length of the system can be determined by locating a nodal point & corresponding

Teacher's Signature \_\_\_\_\_

Observations :-

Table 1:- Observation for the focal length of the lens.

S.No.	lens	Light incident on	Position of cross slit(a) cm	Pos. of lens (b) cm	focal length f(b-d)cm	Mean f cm.
1.	lens 1	One face	30	41	11	10.75
		Other face	30	40.5	10.5	$f_1$
2.	lens 2	One face	30	41.2	11.2	10.66
		Other face	30	40.1	10.1	$f_2$

Table 2:- Observation for the focal length of the comb. of two lenses.

S.No.	Dis. b/w lenses (a) cm	Light incident on	Position of cross slit(a) cm	Position of the nodal slide (b) cm	Exp. f length (b-a) cm	Calculated f length (b-a) cm	Mean calculable (f)
1.	3.8	One face	30	37	7	6.608	
		Other face	3.3	30	37.5	7.5	6.410
2.	5	One face	30	38.6	8.6	7.099	
		Other face	4.2	30	39	9	6.76

Calculation :-

$$\frac{1}{F} = \frac{1}{f_1} + \frac{1}{f_2} - \frac{n}{f_1 f_2}$$

$$F = \frac{f_1 f_2}{f_1 + f_2 - n}$$

(i) For  $n = 3.8$  cm  
for  $n = 5$  cm

$$f = 7 \text{ cm} \quad f_1 = 10.75 \text{ cm}$$

$$f = 8.6 \text{ cm} \quad f_2 = 10.66 \text{ cm}$$

Expt. No. \_\_\_\_\_


Page No. 27 Date \_\_\_\_\_

focal point.

The second nodal point can be located by using the fact that in case of // beam of light incident on a convergent lens system, thus forming an image on a screen in its screen's focal plane, the image does not shift literally when the system is rotated about a vertical axis passing through its second nodal point.

Result :- Focal length of the first lens = 10.75 cm  
focal length of the second lens = 10.66 cm  
Lens formula verified since calculated value of focal length is comparable to the measured value (comb. lenses).

Teacher's Signature \_\_\_\_\_



(b)

Expt. No. \_\_\_\_\_

Page No. 28 Date \_\_\_\_\_

### VIVA- VOCE

1) What is a lens?

→ It is a transparent refracting medium bounded by two spherical surfaces.

2) What is refraction of light?

→ When light travels from one medium to another medium without changing its frequency called refraction of light.

3) What are convex & concave lens?

→ Convex lens is thick at centre & thin at the periphery while concave lens are thin at center & thick at the periphery.

4) What are the focal point?


→ The rays // to principal axis converges at a point are refracted, that pt. is known as focal point.

5) How many?

→ There are a pair of conjugate points which have w.r.t positive angular magnification.

Teacher's Signature \_\_\_\_\_

- It is the distance b/w optical centre & focus points.
- Convex lens converges the light while concave lens diverges the light.



Objective :- Study of motion of charged particle in crossed electric & magnetic field.

Aim :- To study the Hall effect & determine Hall coeff. carrier's density & mobility of a given semi-conductor sample using Hall-effect set-up.

Apparatus Required :-


Hall effect set up Electronics, const. Current power supply, hall probe (Ge crystal, Digital gauss meter etc).

Importance of Hall Effect :-

- 1) The sign of current carrying charge is determined.
- 2) The mobility is measured directly.
- 3) Charge carrier density can be determined from hall coeff.  $R_H$ .
- 4) It can be used to determine the electronic sto. i.e. whether the specimen is metal, semi-conductor or insulator.
- 5) If we know the hall coeff. of a given metal then by the knowledge of hall voltage developed we can calculate the magnetic field.

Observation :-

Magnetic field ( $B$ ) = 4300 Gauss  
 Distance b/w magnetic pole = 1.5 cm  
 Thickness of Sample ( $d$ ) = 0.5 mm  
 Resistivity of Sample ( $\rho$ ) = 6 ohm cm



Expt. No. \_\_\_\_\_

Page No. 31 Date \_\_\_\_\_

Formula Used :-

$$\text{Hall coeff. } R_H = V_H / BI \text{ cm}^3/\text{coulomb}$$

$$\text{Carrier charge density } R_H = 1/n e, n = 1/R_H \text{ cm}^{-3}$$

$$\text{Mobility } \sigma = \text{current} \text{ then } \sigma = \sigma/n e \rightarrow \sigma = R_H n e$$

$$I_{H0} = R_H / \rho \text{ cm}^2/\text{V sec}$$

Observation table :-

S.No.	Current I(mA)	Hall Voltage V(mv)	$V_H/I$
1	0.20	4.0	20
2	1.05	36.5	19.72
3	1.95	38.0	19.48
4	2.05	40.0	19.81
5	0.60	12.1	20.166
6	1.33	38.6	20
7	1.75	33.5	19.14

$$\text{Avg } V_H/I = 19.71$$

$$\frac{l}{B} = 0.5 \text{ mm}$$

$$4300 \text{ Gauss}$$

$$= 0.5$$

$$4300 \times 10^4$$

$$= 1.162$$

$$R_H = 19.71 \times 1.162$$

$$= 22.90$$

$$n = I / R_H e$$

$$= 2.72 \times 10^{19}$$

Teacher's Signature \_\_\_\_\_

Result :-

$$\text{Hall coeff. } R_H = 22.90 \text{ cm}^3/\text{coul.}$$

$$\text{Carrier charge density } n = 2.72 \times 10^{-19} / \text{cm}^3$$

$$\text{Mobility } \mu = 3.816 \text{ cm}^2/\text{v sec.}$$

## VIVA - VOCE

1) Define Hall Effect?

→ When a current carrying specimen is placed in a transverse magnetic field then a voltage is developed which is  $\perp$  to both direction of current & magnetic field. This phenomenon is called Hall effect.

2) What causes Hall Effect?

→ Whenever a charge moves in a mutually  $\perp$  electric & magnetic field, it experiences Lorentz force due to which it deflects from its path & Hall voltage is developed.

3) What is Lorentz force?

→ If a charge 'q' moves in a magnetic & electric field 'B' & 'E' resp. with velocity 'v' then force on it is given by -

$$F = qE + BqV \sin\theta$$

4) What is Hall coeff.?

→ It is the electric field developed per unit current density per unit magnetic field.

5) What are the uses of Hall Effect?

→ To determine the sign of charge carrier & charge carrier concentration.

6) Define charge carrier concentration?

→ No. of charge carriers per unit volume.

7) Why Hall voltage differ for different type of charge carriers?

→ Because direction of Lorentz force is different for different type of charge carriers.

8) What is unit Hall coeff.?

→ Ohm-meter / Tesla.

9) What is the unit of charge carrier concentration?

→ Per Cubic centimeter.

10) Which type of magnet is used in the experiment temporary or permanent?

→ Temporary.

- Objective :-

Study the Stefan's law for radiation

- Aim :-

To verify Stefan's law by electrical method.

- Apparatus :-

- 1- D.C. Voltmeter (0-10 V)
- 2- D.C. Ammeter (0-1 A)
- 3- Small electric bulb (6V, 6W) [having tungsten filament]
- 4- Rheostat (100-2)
- 5- Battery eliminator (6V)

- Formula Used and Theory :-

Stefan's law states that the total radiant energy emitted per second from the unit surface area of a perfectly black body is proportional to the fourth power of its absolute temperature.


$$\text{On } E = \sigma T^4$$

where  $\sigma$  is called Stefan's constant.

In case of black body radiation, Stefan's law is

$$E = \sigma (T_0^4 - T^4)$$

Where  $E$  is the net amount of radiation emitted per second per unit area by a



body at temperature  $T$  and surrounded by another body at Temperature  $T_0$   
for other bodies (other than black)

$$P = A(T^{\alpha} - T_0^{\alpha})$$

where  $P$  is the power emitted by a body at temperature  $T$  surrounded by another at temp  $T_0$ ,  $A \propto Y$  and  $\alpha$  is constt depending on the material and area of such a body.

$$P = AT^{\alpha} \left[ 1 - \frac{T_0^{\alpha}}{T^{\alpha}} \right]$$

when  $T \gg T_0$ ,  $\left( \frac{T_0}{T} \right)^{\alpha}$  can be neglected

$$P = AT^{\alpha}$$

Taking log both sides

$$\log_{10} P = \alpha \log_{10} T + \log_{10} A$$

The graph b/w  $\log_{10} P$  versus  $\log_{10} T$  will be a straight line. Its slope will give the value of ' $\alpha$ '

Therefore do verify Stefan's law  $P$  and  $T$  should be measured.

#### Observation:

Table 1. Determination of  $R_g$ : filament temperature <sup>book</sup>

S.No.	Current Increasing	$R_g = \frac{V}{I}$	Current decreasing
1.	0.6	0.14	4.28

Teacher's Signature: \_\_\_\_\_

Date \_\_\_\_\_

Expt. No. \_\_\_\_\_

Page No. 72

2.	0.8	0.16	5	3.6	0.32	<del>11.2</del> 11.2
3.	1	0.18	5.55	2.4	0.28	<del>8.5</del> 8.5
4.	1.2	0.18	6.66	1.2	0.18	<del>6.6</del> 6.6
5.	1.4	0.2	7	1	0.18	6.6 5.5
6.	1.6	0.22	7.2	0.8	0.16	5.5 5
7.	1.8	0.24	7.5	0.6	0.14	5 4.2
8.	2	0.24	8.3	0.4	0.12	4 3.3

$$\text{Mean}_1 = 6.44$$

$$\text{Mean}_2 = 7.1$$

$$\text{Mean value of } R_0 = \frac{6.44 + 7.1}{2}$$

$$= \frac{13.54}{2} = 6.77 \text{ ohm}$$

Table 2. Determination of Power P; for different temperature T

S.No.	Pot. diff.	Current	$R_t = \frac{V}{I}$	$R_t/R_0$	Temp	$\log_{10} T$	$P = VI$	$\log_{10} P$
1.	0.8	0.16	5	2.9	200	2.3	0.128	-0.8
2.	1.2	0.18	6.6	3.9	500	2.698	0.216	-0.66
3.	1.6	0.22	8	4.7	600	2.778	0.352	-0.45
4.	4	0.38	10.5	6.21	800	2.9	1.52	0.18
5.		$R_0 = \frac{6.77}{4} = 1.69$						

• Result: The graph of  $\log_{10} P$  versus  $\log_{10} T$  is a straight line.

Hence  $P \propto T^a$  law is verified.

Because slope comes out to be 4. Hence  $a = 4$

Teacher's Signature: \_\_\_\_\_

• Precautions:

- 1- Use the bulb having tungsten filament
- 2- Increase the current in steps.
- 3- Note down the voltage reading after every change in current.
- 4- Choose the rheostat of appropriate range.

Ex

• Viva-Voce:

Q.1 What is Stefan's law?

Ans Acc to this law the total energy emitted per second from the unit surface area of perfectly black body is proportional to the fourth power of its absolute Temp.

Q.2 What is Stefan's constant?

Ans As  $\propto T^4$ . Here the proportionality constant  $\sigma$  is known as Stefan's constant.

Q.3 What is its value?

Ans Its value is  $5.670 \times 10^{-8} \text{ W/m}^2\text{K}^4$

Q.4 What is a black body?

Ans A body that absorbs all the radiations incident upon it, irrespective of frequency.

Q.5 What is function of Rheostat in this

- Precautions:

1. Use the bulb having tungsten filament
2. Increase the current in steps.
3. Note down the voltage reading after every change in current.
4. Choose the rheostat of appropriate range.

- Viva-Voce:

Q.1 What is Stefan's law?

Ans Acc to this law the total energy emitted per second from the unit surface area of perfectly black body is proportional to the fourth power of its absolute Temp.

Q.2 What is Stefan's constant?

Ans As  $\propto T^4$ . Here the proportionality constant  $\sigma$  is known as Stefan's constant.

Q.3 What is its value?

Ans Its value is  $5.670 \times 10^{-8} \text{ W/m}^2\text{K}^4$

Q.4 What is a black body?

Ans A body that absorbs all the radiations incident upon it, irrespective of frequency.

Q.5 What is function of Rheostat in this

experiment?

Ans Rheostat is used to increase and decrease the value of current flowing in the circuit.

Q.6 what is the temperature at the stage when the tungsten filament first starts glowing?

Ans Filament temperature is 800 K

Q.7 What is  $R_g$ ?

Ans  $R_g$  is the filament resistance at glow [at 800 K]

• Objective :- Study of Tangent Law for magnetic field.

• Aim : To determine the variation of magnetic field along the axis of a circular coil carrying current & to estimate the radius of coil.

• Apparatus Used :-

1. Stewart & Gee type tangent galvanometer

2. Ammeter

3. Battery Eliminator

4. Rheostat

5. Spirit level

6. Reversing key on a commutator

7. A plug key

8. Sand paper & connecting wires.

• Theory :

If a current of 'I' units be flowing through 'l' length of wire bent into an arc of 'r' radius, the magnetic field intensity (F) at the centre of arc is given by

$$F = \frac{\mu_0}{4\pi} \cdot \frac{Il}{r^2}$$

where  $\mu_0 = 4\pi \times 10^{-7}$  N/A-m and is known

as the permeability of free space.

If the wire forms one complete circle  $l = 2\pi r$

$$F = \frac{\mu_0}{4\pi} \cdot \frac{I \cdot 2\pi r}{r^2} = \frac{\mu_0 I}{2r}$$

for a circular coil carrying 'n' turns

$$F = \frac{\mu_0 n I}{2r} = \frac{2\pi n I}{r} = \frac{2\pi n I \times 10^7}{r}$$

Hence  $F \propto n$   
 $\propto I$

In order to study the effect of 'n' and 'I' on the magnetic field intensity  $F$ , the coil is placed in the magnetic meridian. The magnetic field due to the current 'I' flowing in the coil is perpendicular to  $H$  (Horizontal component of earth's magnetic field) and the magnetic needle is acted upon by two uniform magnetic field  $F$  and  $H$  which are at right angles to each other.

The field  $F$  along the axis of a coil is given by

$$F = \frac{2\pi n r^2 I}{10^7 (x^2 + r^2)^{3/2}}$$

Where  $x$  is the distance of the point from the centre of the coil.

When  $x=0$  i.e., at centre

$$F = \frac{2\pi n^2 I}{10^7 r^3} = \frac{2\pi n d}{10^7 \times r}$$

Let the magnetic needle make angle  $\theta$  with  $H$  in the equilibrium position.

Acc to the tangent law:-

$$\propto F = H \tan \theta$$

Since ' $H'$  is constl at the place of experiment

$$\tan \theta = \frac{2\pi n g^2 I}{H(x^2 + n^2)^{3/2}} \times 10^{-7}$$

Description of Apparatus -

Stewart and Gee tangent galvanometers consists of an insulated circular coil. The ends of these sets of coil are connected to the binding screws, fixed at the base-board of the instrument. One terminal is common to all the coils. A compass box is placed inside the coil such that it can slide on the bench in such a way that the centre of the needle always lies on the axis of the coil. The distance of the needle from the centre of the coil can be read on the graduated scale fixed on the arms of the compass box.




Fig. 7.1 Tangent Law

• Observations:

S.No.	Distance of needle from the centre, x cm	Current one way $\theta_1$	Current reversed $\theta_2$	Mean tan $\theta$
#	θ			$\theta_3$ $\theta_4$
1-	0	68	70	65    65    67    2.35
2-	5	60	62	58    57    59.5    1.69
3-	10	40	42	40    35    39.25    0.81
4-	15	28	23	18    20    20.25    0.37
5-	20	10	14	14    10    12    0.21
6-	25	5	10	8    4    6.75    0.12
7-	30	4	8	5    1    4.5    0.08

Table 2: for other side

S.No	Distance of needle from the centre, x cm	Current one way	Current Reversed	Mean	tanθ
1-	0	68	70	65	67    2.35
2-	5	64	65	60	59    62    1.88
3-	10	45	48	42	40    43.7    0.95
4-	15	24	28	24	21    24.25    0.45
5-	20	12	15	14	10    12.75    0.23
6-	25	5	8	10	6    7.25    0.12
7-	30	1	4	8	5    4.5    0.08

Teacher's Signature : \_\_\_\_\_


Result:- The graph shows the variation of magnetic field along the axis of a circular coil carrying current. The distance b/w the points of inflection A, B gives the diameter of the coil, and hence the radius of the coil =

#### Precautions:-

1. Clean the ends of the connecting wires with sand paper. The connection should be clear & tight.
2. Always use a key in the battery and remove the plug of the key while making connections as well as after each reading is taken.
3. The coil should be adjusted properly in the magnetic meridian.
4. The apparatus must be at considerable distance from current carrying conductors & magnetic material.
5. The +ve marked terminal of the ammeter should always be connected to the +ve pole of the battery.
6. While reading the deflection, avoid error due to parallax.
7. Reading of both ends of the pointer

Topic .....

Date .....



Expt. No. ....

should be taken.

Viva-Voce :

1. What is the magnitude of the field at the centre of the coil?

$$\rightarrow H = \frac{\mu_0 n i^2}{2(\rho^2 + y^2)^{3/2}}$$

$$H = \frac{\mu_0 n i^2}{2n^3} = \frac{\mu_0 i}{2n} = 2 \times 10^{-7} ni$$

$$ni = \frac{2 \times 10^{-7} i}{10^4}$$

where 'n' is the radius of the coil & 'n' is the no. of turns in it.

2. If any current carrying conductor is placed close to the coil then will it effect measurement?

$\rightarrow$  Yes

3. Define (a) Magnetic meridian (b) equatorial line

$\rightarrow$  Magnetic meridian is a vertical plane passing through the magnetic axis of a finely suspended magnet at a place.

equatorial line is a straight line perpendicular to the magnetic axis through its middle point.

Teacher's Signature : \_\_\_\_\_

4. What is meant by point of inflection?

→ Point of inflection is the point where the slope of the curve changes suddenly.

5. How does the field vary along the axis of the coil?

→ The variation of the field along the axis of the coil is shown in (fig 7.4). The points at which curve changes its direction of curvature are called point of inflection. The distance b/w them is equal to the diameter of the coil.

6. Is the field uniform at the centre?

→ It is uniform only over a very small region at the centre.